



MODBOXTM

diy insect in amber

This project is a two-stage pour so your insect gets suspended in the middle of the amber - not sunk at the bottom. So, we suggest you **FIRST** pour and cure a half-fill "base." After ~12 hours, when that layer is firm, you place the insect on top and pour the rest. That way it stays centered for a clean, amber look.

Step by Step Instructions. You can also follow along with the video via the QR code from this product's packaging.

1. Prep (gloves on!) Cover your workspace, level the silicone egg mold, and work in a ventilated area.
2. Mix **HALF** of the resin (100 ml total): Measure 50 ml Part A + 50 ml Part B in the measuring cup. Mix thoroughly (scrape sides/bottom) - like really thoroughly! Add a few drops of yellow until you like the amber tone.
3. Pour: Slowly pour into the mold to about halfway. Gently tap the mold to release bubbles. **DO NOT ADD THE INSECT.**
4. Cure ~12 hours: Let the first layer dry/partially cure until firm to the touch (slightly tacky is OK).
5. Place insect: Set the insect on the cured surface (legs down). Nudge it to center.
6. MIX #2 (100 ml total): Measure 50 ml Part A + 50 ml Part B. Mix thoroughly and tint to match.
7. Final pour: Fill the mold to the top, fully covering the insect. Tap gently to release bubbles and re-center if needed.
8. CURE #2: Let it fully harden (typically 12–24 hours, or per resin instructions) before demolding.